

## **233600S01 - Air Terminal Units**

### **I VAV Boxes:**

All VAV boxes and control valves must have, at minimum, a 24" x 24" access space for maintenance, including removal of coils, damper arms, reheat valves, etc. Space must be maintained to top of acoustical ceiling grid.